

Medical & Mortuary Products



Product Name:

Hospital Pattern Plaster Sink

Product Code:

VANTPSH1200X600LHB/S

Product Description:

A plain top of Stainless Steel with no tap holes, no upstand, edges rimmed and turned down, underside sound-deadened with smooth, impermeable, easily cleaned material. The top incorporates a rectangular sink bowl without overflow with a round sump, containing a partially perforated Stainless Steel basket and covered by a close fitting Stainless Steel cover with plunged handle. Available with two bowl sizes.

Variations

- VANTPSH1200X600RHB/S - Right Hand Small bowl 500mm x 400mm
- VANTPSH1200X600RHB - Left Hand bowl 500mm x 500mm
- VANTPSH1200X600RHB - Right Hand bowl 500mm x 500mm

Technical Specification:

<i>Construction:</i>	Pressed, folded and welded.	<i>Net Weight:</i>	14.5Kg
<i>Material:</i>	304 Stainless Steel	<i>Dimensions:</i>	1200mm x 600mm
<i>Material Thickness:</i>	1.2mm	<i>Fixings:</i>	Canti-lever Wall Brackets

